

Installation Instructions

安裝說明書

REAR SWAY BAR
後防傾桿, 19mm
#Q0430

Application 適用車型

SUBARU XV / CROSSTREK '18 - (GT)
SUBARU FORESTER '18 - (SK)

Components 內含配件

- ① Sway bar 防傾桿桿身..... 1pcs
- ② Bushing 橡皮..... 2pcs

Caution 注意事項

- Installation is recommended to be performed by licensed mechanics with necessary tools to ensure safety. Incorrect installation may cause injury, damage to the product or vehicle.
安裝建議由合格的技師及工具執行以確保安全。安裝錯誤可能對人員、產品及車輛造成傷害。
- Note the routing of wires and cables before installation, or please refer to factory manual.
安裝前請事先記下線路的安裝路徑及位置以維持原廠配置。有疑問時請參考原廠手冊。
- Tighten bolts and nuts firmly by using handtools, and with specified torque if mentioned.
安裝過程請使用手動工具確實鎖緊螺帽及螺絲。如有特別註明請依照說明指示的扭力上鎖。

Instructions 安裝說明

1. Unplug ABS wires to get better access to remove the bar.
將ABS感應線斷開以避免安裝時扯斷。
2. Disconnect sway bar end links.
將防傾桿連接桿(李仔串)卸下。
3. Remove sway bar bushing clamps.
將防傾桿固定環拆下。
4. Remove the bushing clamps mounting brackets.
將防傾桿固定環支架拆下。
5. Pull out the factory sway bar.
將原廠防傾桿穿繞取出。
6. Install the Hardrace sway bar in place.
將新的防傾桿安裝至車輛。
7. Install supplied sway bar bushings onto the Hardrace sway bar.
將附件橡皮安裝於新的防傾桿桿身。
8. Reinstall the bushing clamps and brackets.
將固定環、固定環支架重新鎖上。
9. Reinstall sway bar end links and ABS wires.
將防傾桿連接桿(李仔串)、ABS感應線重新裝上。

