

# Installation Instructions

## 安裝說明書

FRONT SWAY BAR

前防傾桿

#Q1130

### Application 適用車型

MG HS '19-

### Components 內含配件

- ① Sway bar 防傾桿桿身.....1pc
- ② Bushing 橡皮.....2pcs
- ③ Bushing bracket 橡皮固定座.....2pcs

### Caution 注意事項

- Installation is recommended to be performed by licensed mechanics with necessary tools to ensure safety. Incorrect installation may cause injury, damage to the product or vehicle. 安裝建議由合格的技師及工具執行以確保安全。安裝錯誤可能對人員、產品及車輛造成傷害。
- Note the routing of wires and cables before installation, or please refer to factory manual. 安裝前請事先記下線路的安裝路徑及位置以維持原廠配置。有疑問時請參考原廠手冊。
- Tighten bolts and nuts firmly by using handtools, and with specified torque if mentioned. 安裝過程請使用手動工具確實鎖緊螺帽及螺絲。如有特別註明請依照說明指示的扭力上鎖。

### Instructions 安裝說明

1. Remove exhaust pipe, then disconnect sway bar end link, steering rack, rear lower engine mount from front subframe.

將排氣管頭段拆卸，並將李仔串/防傾桿連接桿、方向機及後下引擎腳從大樑/副車架上斷開。

2. Support both front & rear part of front subframe using hydraulic trans jack stands.

使用液壓千斤頂頂住大樑/副車架的前端及後端。

3. Drop the rear part of the subframe until accessible to front sway bar.

將大樑/副車架後端降下，下降至有足夠空間更換防傾桿的位置即可。

4. Replace the factory swat bar with the new sway bar with supplied bushings and brackets.

將原廠防傾桿更換為新的防傾桿，包含附件橡皮以及固定座。

5. Reinstall all the disconnected parts to the vehicle.

依照以上步驟反向將卸下的部件裝回車輛。

※ Adjustable length sway bar end links recommended to fine adjust sway bar angle.

可使用可調長度型李仔串/防傾桿連接桿，微調至最適當的防傾桿高低位置。

